



NOTES:

- ① 10° MIN. FOR WYE LATERAL CONNECTION
- ② FITTING OR LONG RADIUS BEND
- ③ SERVICE WYE WITH PIPE EXTENSION TO GRADE
- ④ WATERTIGHT END PLUG (EASILY REMOVABLE)
- ⑤ PLACE WELL COMPACTED BEDDING MATERIAL 18" UNDER WYE BRANCH, FITTING, AND UNSUPPORTED PIPE. WHEN BEDDING MATERIAL IS USED, PLACE ADDITIONAL MATERIAL TO TOP OF BEND, THE FULL WIDTH OF TRENCH.

SIERRA LAKES  
COUNTY WATER  
DISTRICT

LATERAL AND  
CLEANOUT  
ASSEMBLY  
SEPTEMBER 12, 2008

FIGURE 4